

DOS0015

double piston



Operating manual for double piston oil deadweight tester 0.015% accuracy






Table of Contents

| | |
|--|---|
| 1 introduction..... | 1 |
| 1.1 general product description..... | 1 |
| 1.2 operating principle..... | 1 |
| 2 general specifications..... | 2 |
| 2.1 hydraulic scheme..... | 2 |
| 2.2 instrument outline..... | 3 |
| 3 installation..... | 4 |
| 3.1 site requirements..... | 4 |
| 3.2 changing the piston cylinder assembly..... | 4 |
| 3.3 filling up..... | 4 |
| 4 operating instruction..... | 6 |
| 4.1 working instruction..... | 6 |
| 4.2 determine of the pressure..... | 7 |
| 5 maintenance..... | 8 |
| 5.1 changing the liquid..... | 8 |
| 5.2 recalibration..... | 8 |
| 6 parts list..... | 9 |

1 introduction

1.1 general product description

The model DOS0015 Pressure Standard is an oil operated deadweight tester used for calibrating test gauges, transducers and transmitters. The system consists of the following main components :


| | |
|----------------------------|---|
| deadweight tester platform | 1 |
| piston cylinder assembly | 1 off built in and 1 off separate delivered |
| mass set | 1 set |
| pressure control | manually oil operated variable volume |

The oil lubricated / oil operated pistons of the DOS0015 series are specially designed to have superior performance and a high range ability.

1.2 operating principle

The primary function of the deadweight tester is to combine two primary metro logical quantities:

1. the piston-cylinder which defines an effective area, A .
2. the masses, value m , which press on the piston with a force F .




2 general specifications

| | | |
|--------------------------------|---|-------------------|
| measurement uncertainty p^* | $1.5 \cdot 10^{-4} \cdot p_e$ (of reading) | |
| certification | standard delivered with company certificate (EA ¹ traceable) | |
| pressure connection | 3/8" BSP LH | with BSP adapters |
| footprint base plate | 340 (w) x 225 (d) | mm |
| maximum size | 340 (w) x 430 (d) | mm |
| overall height (excl. weights) | 210 | mm |
| overall height (incl. weights) | Max. 450 (depending on range) | mm |
| pressure media oil | DWT oil Nuto H 32 | Esso |


* when using the formula of chapter 4.2.

2.1 hydraulic scheme



1 European Accreditation, see <http://www.european-accreditation.org>

2.2 instrument outline



3 installation

3.1 site requirements

The DOS0015 is delivered with a mounting plate which is designed to contain the platform and variable volume pump. BSP adapters are also included in the scope of delivery.

- The room in which the instrument is placed should have proper founding, no vibrations are allowed during operation of the DOS0015 as this results in unpredictable errors.
- The DOS0015 should be placed on a rugged table which is rated for at least 140 kg without deforming. The table should be horizontally leveled. The DOS0015 can be places on the table without fixation. Or can be fit the a table using the extra set of leveling nuts. Use the stencil to mark the screw holes.
- Air movement around the DOS0015 should be avoided.
- Room temperature needs to be stable during the time the DOS0015 is used to avoid uncertainties due to the thermal expansion coefficients of the piston cylinder and adiabatic effects in the measuring system.

3.2 changing the piston cylinder assembly

To change from low pressure range to the high pressure range it is necessary to change the piston cylinder assembly.

1. make sure there is no pressure in the unit
2. unscrew the piston cylinder assembly
3. make sure the table stays free of oil and grease
4. take out the O-ring
5. close the valve (anti clockwise, max 2 turns)
6. fill the piston cylinder assembly adapter up to the thread level
7. mount the O-ring on the piston cylinder assembly
8. mount the piston cylinder assembly in the adapter
9. tighten it with a wrench
10. clean the adapter from oil
11. the deadweight tester is ready for use



3.3 filling up

Before connecting any external device it is good practice to fill up the DOS0015 first.

1. make sure there is sufficient liquid (Nuto H 32 oil) in the reservoir
2. open the valve (clockwise, till its mechanical stop)
3. rotate the screw pump clockwise until it hits its end stop
4. block the pressure connection with a plug or a finger
5. rotate the screw pump anti clockwise until it hits its end stop (the pump is filled with liquid)
6. close the valve (anti clockwise, max 2 turns)
7. unplug the pressure connection
8. carefully operate the screw pump until the liquid level is at the sealing of the pressure connection
9. mount the pressure instrument (instrument under test)
10. carefully operate the screw pump (clockwise) up to maximum 10 bar
11. carefully open the valve, the pressure will be reduced and air will be pressed out
12. repeat step 10 and 11 until no air bubbles escape when the valve is opened
13. the deadweight tester is ready for use

4 operating instruction

4.1 working instruction

1. before using the deadweight tester, check oil reservoir and if necessary fill up with Nuto H 32 oil (see chapter 3.2 for filling up)
2. place the instrument on a firm level base
3. check if the bubble level is in the center, if not: level the instrument with the leveling nuts
4. the instrument under test may be connected to the tester, using one of the adapters supplied
5. the correct number of weights to give the pressure desired may be placed on the piston cylinder
6. open isolation valve (clockwise, till its mechanical stop)
7. turn screw pump clockwise till end of its stroke
8. turn screw pump contra-clockwise till end of its stroke
9. close isolation valve (anti-clockwise, max. 2 turns)
10. turn screw pump slowly clockwise until the carrying table floats about 3mm higher than the pillar
11. rotate the weights and piston cylinder assembly clockwise
12. collect the readout of the instrument under test together with the mass load of the deadweight tester and file them
13. carefully change the mass load to realize the next pressure step
14. continue with 10)
15. after the test, turn the screw pump contra clockwise until the piston has reached its end stroke and open the isolation valve
16. remove the weights and remove the pressure gauge

4.2 determine of the pressure

The reference level of the deadweight tester is at the top of the sealing of the pressure connection.

If the weight set is marked with a pressure unit (bar; psi or kg/cm²) the pressure can be determined by the formule:

$$p_e = (p_0 + \Sigma p_c) \cdot \frac{g_1}{g_n}$$

| | | | |
|-------|--------------|---|---------------------------------|
| where | p_e^* | : Gauge pressure at reference level | [bar; psi; kg/cm ²] |
| | p_0 | : Starting pressure piston + plate | [bar; psi; kg/cm ²] |
| | Σp_c | : Summarized pressure equivalent of the weights | [bar; psi; kg/cm ²] |
| | g_1 | : Local gravity | [N/kg] |
| | g_n | : Normal gravity (9.80665) | [N/kg] |

* The value of the pressure p_e which puts the piston into equilibrium.

When using this formula the maximum error will not exceed 0.03% of reading. To reach the maximum accuracy of 0.015% of reading the following formula has to be used:

$$p_e = \frac{m_c \cdot (1 - \rho_a / \rho_m) \cdot g_l + \tau \cdot \pi \cdot d}{A_0 \cdot (1 + \lambda \cdot p) \cdot (1 + (\alpha_p + \alpha_c) \cdot (t - 20))} \cdot 10^{-6} \quad [\text{MPa}]$$

| | | |
|-----------------------|---|------------------------------------|
| p_e^* | : gauge pressure at reference level | [MPa] |
| m_c | : conventional mass | [kg] |
| $1 - \rho_a / \rho_m$ | : air buoyance correction | (= 0,99985) [-] |
| g_l | : local gravity | [N/kg] |
| τ | : surface tension NUTO H32 | (= 0,031) [N/m] |
| $\pi \cdot d$ | : piston circumference | [m] |
| A_0 | : effective area at zero pressure | [m ²] |
| λ | : pressure distortion coefficient piston + cylinder | [MPa ⁻¹] |
| p | : nominal line pressure | [MPa] |
| $\alpha_p + \alpha_c$ | : thermal expansion coefficient piston + cylinder | (= 3.0 · 10 ⁻⁵) [1/°C] |
| t | : piston temperature | [°C] |

* The value of the pressure p_e which puts the piston into equilibrium.

The conventional masses m_c , the coefficient λ and the effective area A_0 are listed in the calibration certificate.

5 maintenance

The entire tester should be kept clean as dirt and grit will cause rapid wear.

As instruments to be tested come from an unknown process it is likely that the inside of the instrument is contaminated, this will in time contaminate the inside of the deadweight tester.

To guarantee the performance of the deadweight tester it is good practice to change the Nuto H 32 oil once a year (dependent on the use and local conditions).

5.1 changing the liquid

1. open the valve
2. rotate the screw pump clockwise until it hits its end stop
3. take out the liquid
4. blow through the pressure connection with low pressure air
5. clean the reservoir
6. see chapter 3.2 purging

5.2 recalibration

Although the DOS0015 is designed to have a very good long term stability, a first recalibration at 2 years after purchase is recommended both for piston cylinder and mass set. The results of the recalibration can be used as a guideline for future recalibration. Depending on the environment and frequency of use a recalibration interval of 2 to 5 years is normal.

6 parts list

| Part | Code | Qty. | Remark |
|---------------------------|--------------------------------|----------|------------------------------------|
| Base plate | 340 x 225 mm | 1 | |
| Piston cylinder assembly | | 1 | Including start weight |
| Oil hand pump | | 1 | 16 mm piston |
| U-cup | Merkel T20 8-16-5.7 1 | 1 | In piston of oil pump |
| Back-up ring | PTFE | 1 | In piston of oil pump for U-cup |
| O-ring in piston assembly | Ø21,82 x 3,53 mm 90° shore | 1 | In piston of oil pump |
| Oil reservoir and valve | | 1 | |
| O-ring in valve | Ø5.23x2.62 mm 90° shore | 1 | |
| Leveling nut | M10 x 55 mm | 4 | For base plate |
| Fixed level nut | M10 x 55 mm | 4 | For base plate |
| O-ring | Ø22 x 2,5 mm 90° shore NBR | 1 | For mounting oil reservoir |
| O-ring | Ø15,88 x 2,62 mm 90° shore NBR | 1 | For mounting hand pump |
| O-ring | Ø18,6 x 2,4 mm 90° shore NBR | 3 | For mounting pressure connections |
| Adapter 1/2" bsp | E-27-301-14 | 1 | |
| Adapter 3/8" bsp | E-27-301-26 | 1 | |
| Adapter 1/4" bsp | E-27-301-15 | 1 | |
| Adapter 1/8" bsp | E-27-301-25 | 1 | |
| Multi seal | 065-260-09 | 2 | Ø13,2 x 6,9 x 1,3 mm, for adapters |
| Certificate | | 1 | Traceble to European standard |
| Weight box | | 1...3 | for weight set |
| Deadweight tester oil | Nuto H 32 | 0.5 ltr. | Esso |



Stiko Meetapparatenfabriek B.V.
Industrieweg 5, 9301 LM RODEN
P.O. Box 46, 9300 AA RODEN
The Netherlands
Tel. : +31 - (0)505013813
Fax.: +31 - (0)505013824
E-Mail: sales@stiko.nl
www.stiko.nl